

Cone Crusher Parts List

We support the following parts of **Sandvik Cone Crusher** models. If you do not find the corresponding picture number in the following table, please contact our sales staff directly. We will give you feedback as soon as possible.

SANDVIK CONE LINERS

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
452.0273-903	CONCAVE LOWER	BG00228529	CONCAVE
452.0274-003	CONCAVE UPPER	452.6115-002	MANTLE
442.8070-03	MANTLE	452.3822-902	CONCAVE
452.5920-902	CONCAVE LOWER	452.1464-902	CONCAVE
442.9339-02	MANTLE	452.1465-902	CONCAVE
452.0264-002	MANTLE	442.7230-03	MANTLE
452.1067-002	CONCAVE	442.8821-03	MANTLE
442.7988-03	MANTLE	442.9230-03	CONCAVE
442.8817-01	CONCAVE	452.3027-003	CONCAVE
442.9288-02	MANTLE	442.7225-03	MANTLE
452.7003-902	CONCAVE	442.8422-02	BOWL LINER
452.8233-02	MANTLE	452.0842-02	CONCAVE
452.8231-02	CONCAVE	452.0838-02	CONCAVE
442.8249-03	CONCAVE	452.0837-02	MANTLE
442.7989-03	MANTLE	452.0832-02	CONCAVE
442.8247-03	CONCAVE	442.8246-02	CONCAVE
452.7548-003	MANTLE	442.6878-02	CONCAVE
452.7548-002	MANTLE	452.2253-02	CONCAVE
BG00228531	CONCAVE	452.2255-02	CONCAVE

BG00228530	CONCAVE	452.0872-02	MANTLE
442.9398-02	CONCAVE	442.8983-02	MANTLE
442.9314-02	MANTLE	442.8070-02	MANTLE
452.0840-02	CONCAVE	442.8089-02	MANTLE
452.0845-02	MANTLE	442.8114-90	CONCAVE
452.1216-002	CONCAVE	442.8115-90	CONCAVE UPPER
452.0274-002	CONCAVE UPPER	442.8099-90	CONCAVE UPPER
452.0273-902	CONCAVE LOWER	442.8098-90	CONCAVE LOWER
442.8522-90	CONCAVE LOWER	442.8470-02	MANTLE
442.9073-02	MANTLE	442.8471-02	MANTLE
442.8039-02	MANTLE	442.8485-90	CONCAVE UPPER
442.8418-02	CONCAVE	442.8477-90	CONCAVE
442.8420-02	CONCAVE	442.8478-02	CONCAVE
442.8419-02	CONCAVE	442.8484-90	CONCAVE UPPER
442.8417-02	CONCAVE	442.6789-02	MANTLE
442.8416-02	CONCAVE	442.7379-90	CONCAVE UPPER
452.3027-02	CONCAVE	442.8464-90	CONCAVE LOWER
442.6859-02	MANTLE	442.8550-90	CONCAVE
442.6873-02	CONCAVE	442.8821-02	MANTLE
442.8982-02	MANTLE	442.8819-02	MANTLE
442.8981-90	CONCAVE UPPER	442.9355-02	MANTLE
442.8979-90	CONCAVE LOWER	442.8817-02	CONCAVE
442.9072-90	CONCAVE UPPER	442.8815-02	CONCAVE
442.9071-90	CONCAVE	442.9356-02	CONCAVE
442.8814-02	CONCAVE	442.8630-02	CONCAVE
442.8820-02	MANTLE	442.8251-02	CONCAVE
442.9760-02	MANTLE	442.7989-02	MANTLE

442.8816-02	CONCAVE	442.7988-02	MANTLE
442.8818-02	CONCAVE	442.9761-02	MANTLE
442.8813-02	CONCAVE	442.7000-02	MANTLE
442.9230-02	CONCAVE	442.6197-02	MANTLE
442.7230-02	MANTLE	442.9698-02	MANTLE
442.7225-02	MANTLE	442.9585-02	CONCAVE
442.8421-02	CONCAVE	442.9586-02	CONCAVE
442.8247-02	CONCAVE	442.9584-02	CONCAVE
442.8249-02	CONCAVE	442.9583-02	CONCAVE
442.8248-02	CONCAVE	442.9569-02	CONCAVE
442.9587-02	CONCAVE		

SANDVIK CONE SPERA PARTS

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
452.4151-001	DUST COLLAR	868.0799-00	SPHERICAL ROLLER BEARING
452.0230-901	BOTTOM SHELL	984.0391-00	TRANSDUCER PROBE
442.8093-00	TOP SHELL ASSEMBLY	906.0377-00	HYDROSET PUMP
452.1699-901	MAINSHAFT ASSEMBLY	863.0058-00	DISC SPRING
650.0173-03	HYDRAULIC HOSE	442.7524-01	SCRAPER
442.1901-00	HYDRAULIC HOSE	984.1008-00	LIQUID LEVEL SWITCH
650.0097-12	HYDRAULIC HOSE	442.8731-01	STEP WASHER
650.0092-21	HYDRAULIC HOSE	442.8809-04	SHIM
442.7093-02	PINION	442.8809-03	SHIM
875.0276-00	V BELT	442.8809-02	SHIM
879.0359-00	PULLEY, V BELT	442.8809-01	SHIM
984.1504-00	PRESSURE TRANSMITTER	442.8729-01	HUB
984.1503-00	TEMPERATURE TRANSMITTER	442.8761-01	ECCENTRIC WEARING PLATE
442.9966-00	PINIONSHAFT HOUSING	442.7168-04	SHIM
442.7259-901	MAINSHAFT ASSEMBLY	442.7168-03	SHIM
442.8733-01	ECCENTRIC	442.7168-02	SHIM
442.7151-01	ECCENTRIC	442.7168-01	SHIM
442.7142-01	HUB	873.1208-00	OIL SEAL RING
910.0102-00	AIR-OIL COOLER	442.8823-01	FILLER RING
442.7093-00	DRIVE GEAR PAIR	442.8863-01	FILLER RING
442.7103-01	RETAINER RING	442.7169-00	RING
442.7190-01	ARM SHIELD	912.0114-00	AIR FILTER
868.0806-00	BEARING	BG00259473	STEP BEARING SET
831.0016-00	CASTING COMPOUND	442.8075-01	ARM SHIELD

864.0080-00	RUBBER COMPRESSION MOUNT	442.8075-00	ARM SHIELD
442.9042-01	WEAR PLATE	452.4412-901	DUST RING
442.9041-01	NARROW ARM SIDE LINER	875.0269-00	BELT
442.9040-01	WEAR PALTE	442.8739-00	CHEVRON PACKING
906.0373-00	SEAL	442.8743-00	RING
442.8761-001	ECCENTRIC WEARING PLATE	442.7192-90	FEED HOPPER CONE
442.8742-001	BOTTOM SHELL BUSHING	442.7192-00	FEED HOPPER CONE
873.1161-00	OIL SEAL RING	442.7106-01	DUST COLLAR
442.8008-01	FILLER RING	452.5543-901	FILTER KIT
442.7930-01	RING	442.6635-00	DAMPER
442.7951-01	BEARING COVER	442.9043-01	WEAR PLATE
442.9936-01	PINIONSHAFT	442.7923-01	ECCENTRIC BUSHING
442.8009-01	RING	442.7931-01	INNER SEAL RING
452.5797-901	LOCKING BAR KIT	442.9035-01	TOP SHELL LINER
442.7267-90	FEED DISTRIBUTER	442.8451-01	ARM SHIELD
442.7267-00	FEED DISTRIBUTER	400.0778-01	JAW WEDGE
442.8553-00	TOP SHELL ASSEMBLY	442.9643-01	ECCENTRIC BUSHING
442.7100-01	MAINSHAFT	442.9642-01	ECCENTRIC BUSHING
452.4130-902	HEAD ASSEMBLY	BG00325390	MAINSHAFT SLEEVE
452.4130-901	HEAD ASSEMBLY	442.8975-01	RIM LINER
452.0328-01	MAINSHAFT	442.7108-01	SEAL RING
452.0918-01	MAINSHAFT	442.8826-01	ECCENTRIC BUSHING
452.3271-01	MAINSHAFT	BG00213813	MAINSHAFT SLEEVE
452.4309-01	MAINSHAFT	891.1647-901	INSPECTION DOOR PU
452.3274-01	MAINSHAFT	891.2133-901	RUBBER PLATE KIT
442.8767-01	MAINSHAFT	442.8794-01	WEAR PLATE

452.0239-001	WEAR PLATE	442.8798-01	WEAR PLATE
452.0238-001	WEAR PLATE	442.8797-01	WEAR PLATE
442.7180-01	TOP SHELL	442.8796-01	WEAR PLATE
452.4191-001	ECCENTRIC BUSHING	442.8795-01	WEAR PLATE
442.7115-001	BURNING RING	442.7902-01	MAINSHAFT
442.7523-01	RETAINER	442.7110-01	LOCATING BAR
442.8805-01	SCRAPER	864.0046-00	DAMPER
442.8804-01	RETAINER	442.7136-03	GASKET
855.0026-00	RETAINING RING	442.7136-02	GASKET
442.8763-01	MANTLE HEAD	442.7136-01	GASKET
853.0119-00	DOWEL PIN	442.7170-01	GASKET
442.8970-01	TOP SHELL	912.0374-00	FILTER INSERT
442.8290-01	DOWEL PIN	442.9036-01	RIM LINER
442.8425-01	SUPPORT RING	BG00566260	MAINSHAFT ASSEMBLY
442.7271-01	WASHER	442.8067-01	ECCENTRIC BUSHING
442.7253-01	SLEEVE	452319 M2/W502	BEARING
442.8800-00	HEAD NUT WITH BURNING RING	22219 E/C3	BEARING
873.1025-00	V RING	442.7949-01	PINIONSHAFT HOUSING
442.9037-00	TOP SHELL EC2	442.7950-01	PINIONSHAFT HOUSING
442.8735-00	BOTTOM SHELL	442.7952-01	PINIONSHAFT
442.8313-901	MAINSHAFT ASSEMBLY	442.7802-02	PINION
442.8020-01	RETAINING RING	442.7954-01	SPACER
452.4190-001	BOTTOM SHELL BUSHING	442.7935-01	BOTTOM SHELL BUSHING
452.4192-001	ECCENTRIC BUSHING	442.7925-01	ECCENTRIC BUSHING
452.4188-001	ECCENTRIC WEARING PLATE	442.8938-00	PUMP UNIT
452.0655-901	MAINSHAFT ASSEMBLY	442.7492-01	SPIDER CAP

442.7107-01	ECCENTRIC WEARING PLATE	442.7105-00	HEAD NUT
442.7131-01	SPACER	452.6202-901	TOPSHELL
23122 CC/W33/C3	PINIONSHAFT BEARING	442.7117-01	MAINSHAFT SLEEVE
442.7112-00	CHEVRON PACKING	442.8755-01	SEAL RING
442.8333-01	HEAD NUT INNER	442.8754-01	SPIDER BUSHING
442.7146-01	BOTTOM SHELL BUSHING	452.0269-001	BURNING RING
442.9406-01	ECCENTRIC BUSHING	442.8791-01	HEAD NUT INNER
442.8723-00	DRIVE GEAR PAIR	442.8792-01	MAINSHAFT SLEEVE
879.0499-00	PULLEY	442.8825-01	ECCENTRIC BUSHING
879.0497-00	PULLEY	89-442-690-013	WASHER
869.0235-00	BUSHING	873.1008-00	V RING
442.8762-01	LOCATING BAR	923.0379-00	PRESSURE GAUGE
906.0367-00	PUMP	912.0155-00	FILTER CARTRIDGE
442.8801-01	RETAINER RING	912.0139-00	FILTER CARTRIDGE
442.8747-01	INNER SEAL RING	912.0129-00	FILTER CARTRIDGE
442.8732-01	MAINSHAFT STEP	912.0127-00	PRESSURE DROP INDICATOR
442.8730-01	PISTON WEARING PLATE	912.0126-00	FILTER
906.0141-00	PUMP	875.0323-00	BELT
442.8802-01	DUST RING	442.8017-01	DUST SEAL
442.7120-01	MAINSHAFT STEP	442.7918-01	HEAD NUT INNER
442.7121-01	STEP WASHER	442.7895-01	MAINSHAFT STEP
442.7122-00	PISTON WEARING PLATE	442.6473-01	SPIDER BUSHING
442.7102-01	DUST RING	442.8022-01	SCRAPER
442.9408-01	SPIDER BUSHING	442.7913-01	MAINSHAFT SLEEVE
442.7897-00	CHEVRON PACKING	442.7912-00	HEAD NUT
442.7894-01	STEP WASHER	442.7133-01	BEARING COVER

442.7893-01	PISTON WEAR PLATE	442.9684-01	INNER BEARING COVER
873.0128-00	SEAL RING	442.8764-01	PINIONSHAFT HOUSING
442.8793-01	SUPPORT RING	442.8772-01	PINIONSHAFT
442.8753-01	SPIDER CAP	442.8771-01	SPACER
442.7911-01	BURNING RING	442.8766-01	PLATE
442.7105-01	HEAD NUT	442.8765-02	PLATE
442.7915-01	LINER PINIONSHAFT ARM	442.8759-00	LINER NARROW ARM
442.7914-01	LINER NARROW ARM	442.8760-00	ARM GUARD
442.7506-01	PINIONSHAFT HOUSING	442.9269-01	HEAD NUT INNER
442.9937-01	PINIONSHAFT	442.7141-00	NARROW ARM LINER
442.7130-01	INNER SPACER	442.7140-00	LINER PINIONSHAFT ARM
442.0721-01	BOTTOM SHELL BUSHING	442.6427-01	BURNING RING
442.9033-01	ECCENTRIC BUSHING	442.9306-01	BURNING RING
452.1619-001	SPIDER BUSHING	452.0687-001	SUPPORT RING
819.0327-00	HOSE	452.0930-001	HEAD NUT INNER
978.0640-00	I/O MODULE	452.0505-001	MAINSHAFT SLEEVE
819.0328-00	HOSE	442.9294-01	MAINSHAFT SLEEVE
452.0243-901	LINERS IN BOTTOM SHELL	442.9270-00	HEAD NUT WITH BURNING RING
442.8800-01	HEAD NUT	442.8159-90	FEED HOPPER CONE
900.0981-00	BSPT PLUG	442.8159-00	FEED HOPPER CONE
452.0553-001	SPIDER CAP	452.0938-001	BURNING RING
191.2365-00	CONNECTION BOX	442.7109-01	RING
191.2376-00	TEMPERATURE SENSOR	442.6138-01	MAINSHAFT STEP
900.0425-00	COMPRESSION FITTINGS	442.6137-01	STEP WASHER
900.0437-00	COMPRESSION FITTINGS	442.6139-01	PISTON WEARING PLATE
811.0202-00	PIPE	452.2899-001	HOSE
914.0093-00	LUBRICATION NIPPLE	984.0623-00	TRANSDUCER PROBE

452.1060-001	ARM SHIELD	452.1286-001	HOSE
452.0664-901	TOPSHELL	452.1287-001	HOSE
452.0684-901	TOP SHELL ASSEMBLY EXCL CONCAVE	452.1288-001	HOSE
ZT1145-DP	DISTRIBUTOR PLATE	452.0936-901	HEAD NUT
452.0924-001	DUST SEAL	442.6175-01	NARROW ARM LINER
452.0522-901	MAINSHAFT ASSEMBLY	442.6174-01	COUNTERSHAFT GUARD
452.0320-01	MANTLE HEAD	442.8364-01	SEAL
452.0806-001	ECCENTRIC BUSHING	442.6140-01	MAINSHAFT SLEEVE
442.9248-01	BOTTOM SHELL BUSHING	442.6812-00	FEED HOPPER CONE
452.2631-901	STEP BEARING SET	442.6906-01	DUST SEAL RING
442.9360-01	ECCENTRIC BUSHING	442.8363-01	SPIDER BUSHING
452.0808-001	ECCENTRIC WEARING PLATE	442.8362-01	SPIDER CAP
452.0795-001	BOTTOM SHELL BUSHING	442.6194-00	HEAD NUT
452.2630-901	STEP BEARING SET	442.6193-00	HEAD NUT INNER
452.0834-001	LOCATING BAR	442.7910-01	MANTLE HEAD
442.9266-01	SPIDER BUSHING	442.8973-01	ECCENTRIC
452.0540-001	ECCENTRIC BUSHING	879.0437-00	PULLEY
442.9256-01	HYDROSET CYLINDER BUSHING	452.1635-901	HEAD CENTRE MAINSHAFT
452.0969-001	HYDROSET CYLINDER BUSHING	442.8735-ASSY	BOTTOM SHELL
442.7933-04	SHIM	442.8245-01	FILLER RING
442.7933-03	SHIM	442.7912-01	HEAD NUT
442.7933-02	SHIM	442.9164-00	SPIDER CAP
442.7933-01	SHIM	984.0605-00	OIL HEATER
442.7928-01	LOCATING BAR	442.8703-00	PUMP AGGREGAT
442.7934-01	GASKET	442.5663-90	PUMP AGGREGAT
452.5227-001	LINER NARROW ARM	910.0103-00	AIR-OIL COOLER

452.5222-001	LINER PINIONSHAFT ARM	930.0235-00	COUPLING HALF
912.0138-00	AIR FILTER PUROLATOR	930.0234-00	COUPLING HALF
452.5574-901	PINIONSHAFT HOUSING REPAIR KIT	650.0286-01	HOSE
452.5575-901	PINIONSHAFT HOUSING REPAIR KIT	864.0066-00	RUBBER COMPRESSION MOUNT
442.7921-01	ECCENTRIC	904.0499-00	HOSE
442.7976-01	SPIDER CAP	904.0500-00	HOSE
442.6217-01	BURNING RING	869.0286-00	BUSHING
452.8425-01	SUPPORT RING	442.8847-901	PINIONSHAFT ASSEMBLY
452.1634-01	MANTLE HEAD	452.4125-901	BOTTOM SHELL ASSEMBLY
452.1633-01	MAINSHAFT	442.8866-01	WEAR PLATE
442.8332-01	MANTLE HEAD	442.8865-01	WEAR PLATE
442.8869-01	WEAR PLATE	442.8864-01	WEAR PLATE
442.8868-01	WEAR PLATE	442.9667-00	HYDROSET CYLINDER COVER
442.8867-01	WEAR PLATE	442.7889-01	HYDROSET CYLINDER